





Pour Point Process Analyzer PPA-4

Pour Point Process Analyzer PPA-4

Application

The BARTEC BENKE Pour Point Process Analyzer (PPA-4) measures the pour point of petroleum products, hydrocarbons, chemical products and components. The PPA-4 operates online and fully automatic. Two layouts are available:

- **Low temperature** e.g. diesel and light gas oil or similar products
- **High temperature** e.g. fuel, lube and bunker oils or similar products others on request.

BARTEC BENKE

YOUR competent partner for safe plants



Special Features

- Real tilting measuring cell
- Rugged design of measuring cell
- Optimized assembly easy removal of complete cell
- Integrated failure diagnosis and self monitoring
- Available communication interfaces:
 - Modbus/RTU, Modbus/TCP
 - Remote Access via modem, ISDN, LAN, VPN

from BARTEC
BENKE have
many years
of experience in
plant safety.
They create
solutions which
you can rely on:
e c o n o m i c a l,
r e liable and

for the future.

Make your decision for a strong partner!

Choose BARTEC BENKE also for

- Fast Loop Systems
- Sample Conditioning Systems
- Validation Systems
- Recovery Systems
- Chillers
- Air Conditioning Systems/HVAC
- Pre Commissioned Analyzer Shelters/Turn-Key Solutions

BARTEC BENKE



Method

The product sample is cooled under specified conditions. The pour point is the temperature at which the liquid sample becomes solid, detected in the tilting measuring cell of the PPA-4.

Note: Illustrations of this brochure show a typical PPA-4 Analyzer.



Pour Point Process Analyzer PPA-4



Explosion protection

Ex protection type (Europe)

Certification TÜV 99 ATEX 1463

Optional available Class I, Div. 2, Groups B, C and D classification Class I, Zone 1, Groups IIB or IIB+H, (USA and CAN) Protection type depending on application

CSA certificate no. 1524800

Technical data

Method ASTM D 97

DIN ISO 3016

IP 15

Automatic Tilt Method similar

to ASTM D 5950

Results correlate with instruments designed according to ASTM D 5949

Measuring range -30 to +33 °C (-22 to +91 °F)

limited within a range of 30 K

Repeatability ≤ ISO/ASTM Reproducibility ≤ ISO/ASTM

Measuring cycle discontiniuous 15 to 90 min

(depending on pour point temperature)

Product streams 1 x sample, 1 x validation

(additional hardware required)

Electrical data

Nominal voltage AC 230 V ± 10 %, 1 phase; 50 Hz

other rating on request

AC 400 V/50 Hz; 3 phases (for chiller)

Maximum power approx. 600 W

consumption approx. 1100 W (for chiller)

Protection class IP 54

Ambient conditions

Ambient temperature operation 5 to 40 °C (41 to 104 °F) **Ambient humidity**

operation 5 to 80 % relative humidity,

non-corrosive

Sample

Quality clean and drv.

according to standard method

Consumption 20 to 40 l/h Pressure at inlet 1 to 3 bar

normal 30 °C (86 °F), Temperature at inlet max. 50 °C (122 °F),

min. 20 K above pour point temperature

Outlet open to atmosphere

Utilities

■ Instrument air

Consumption min. 1.4 Nm³ per flushing cycle during

~ 0.8 Nm³/h in normal operating mode

only for leak compensation

Pressure at inlet 2 to 5 bar

dew point \leq -40 °C (-40 °F) Quality

> humidity class 2 or better according to ISO8573.1

■ Coolant controlled and supplied by chiller

Signal outputs and inputs

Analog outputs pour point

temperature product

Digital outputs sum alarm, ready signal,

see options

Digital inputs reset, see options Electrical data of signal outputs and inputs

4 to 20 mA 800 Ω out; active isolated on request

Digital outputs DC 24 V; max. 0.5 A

high DC 15 to 28 V **Digital inputs** low DC 0 to 4 V

Auxiliary power DC 24 V: max. 0.8 A supply output

Control unit

Analog outputs

Central control unit Industrial PC Windows XP® **Operating system**

Control software PACS

User interfaces

Display TFT display with touch function

800 x 600 pixels

virtual keyboard, controlled via Keyboard

TFT display

Connections

Pipe fittings Swagelok® 6 mm/8 mm/12 mm

other fittings on request

Vent/Slop open to atmosphere

Weight and dimensions

Weight approx. 420 kg

Dimensions (W x H x D) approx. 1140 x 1900 x 710 mm

Optional signal outputs and inputs

Digital outputs identification of a validation cycle

alarm chiller

warning/low-priority error

Digital inputs request for a validation cycle

MODBUS/RTU via RS485 or RS422 **MODBUS** interface

or fiber optic cable

MODBUS/TCP via fiber optic cable

Remote access via modem, ISDN,

Ethernet via fiber optical or VPN

Important notice PPA-4 is subject to continuous product improvement, specifications may be subject to change without notice.